

Mangonui Cruising Club Inc.
Instructions to Hardstand Users
(Boat owners to have available while using hardstand)

The following mandatory Rules and Regulations for the Mill Bay Hardstand are based on the Resource Consents Mangonui Cruising Club has from FNDC & NRC. The Vessel Owner will be held liable for any damage sustained by 3rd Party

General regulations

- All work on vessel should not affect the maintenance operations of any other Hardstand user.
- **Curtains/Screens** must be in place along the Seaward Side of the Hardstand prior to work starting.
- **Boom** to be placed across the end of the seaward Hardstand area or round the gully trap on the container side to divert sediment from the gully trap.
- Ensure that the **mesh screens** are clean and placed over the gully traps **prior** to water blasting.
- All waste material deposited on the Hardstand Surface and gully trap screens must be bagged and disposed of by the owner. This includes fuel, painting and construction material waste. **Only water run-off should be allowed to enter the gully.**
- The use of drop sheets under vessels is required and must be cleaned up each day.
- When the wind strength is such that any debris cannot be retained within the immediate area, stop work and clean the area.
- All noise levels on the hardstand must be kept within a maximum of 65dBA
- **Ladders and scaffolding** must be secured to the vessel or cradle.
- Vessel owner is responsible for ensuring that **all persons** working on the vessel comply with the ***Hardstand instructions and requirements.***

Sanding Regulations

- Paint and anti-foul removal must be by **Dry Sanding** using a Vacuum system (*available from D B Hire*).
- Dry hand spot sanding and scaping are permitted but drop sheets must be used
- **No Abrasive Sand Blasting** is to be carried out on the Hardstand.

Painting Regulations

- For **any spray painting** the boat must be completely shrouded otherwise **no spraying**
- The area around the vessel must be "Roped Off" with Caution Tape and the ***Caution, Anti-foul Paint being applied*** sign displayed
- Drop sheets must be used for all painting.

Environmental incidents must be reported to the NRC Hotline: 0800 504639

Incidents/Accidents are to be recorded on an Incident/Accident Form

The Hardstand Supervisor must be contacted in all instances:

Mobile: 0224140868 Email: hardstand@mangonucruisingclub.com